

WP-250



Positioner Dimensional Drawings





- 1. Pilot Light: Lights up red to indicate power on.
- 2. Power On-Off Switch
- Speed Control: Provides control of table rotation speed from 0%(0 RPM) to 100%(5 RPM).
- 4. Fuse Holder: Fuse 5 amp
- Forward/Off/Reverse Switch: Controls table rotation. Forward (clockwise rotation) and Reverse (counterclockwise rotation).
- Remote/Panel Switch: Remote = Start and stop are remotely controlled. Panel = Start and stop are operated from the control box.
- 7. Remote Plug: Plug-in for the foot switch to start and stop of the turn table rotation.
- 8. Power in



